



Quick Start



M-Class PCI, PXI, PXIe and VXI Instruments

1

Microsoft Windows 7, Windows 2000/XP/Vista Installation:

Install the instrument software & documentation.

- a** Insert the Software & Documentation CD. If you do not have the CD it can be downloaded from the ZTEC Support Center at www.ztecinstruments.com/support.
- b** If auto-setup does not begin, launch it manually by opening the CD in Explorer and clicking setup.exe. Follow the on-screen installation instructions.

2

Install the instrument hardware.

- a** The instrument hardware is an electrostatic sensitive device. Follow all ESD and safety precautions.
- b** With the power off, install the instrument hardware using the guidelines provided by the chassis or computer manufacturer.

3

Confirm proper installation.

- a** You are now ready to use your instrument! Open the provided software executable, or the programming environment of your choice, to use your instrument.
- b** The instrument driver files are located in C:\Program Files\ZTEC Instruments\MClass by default.
- c** Visit the ZTEC Knowledgebase for text-based programming examples and extra helpful hints at www.ztecinstruments.com/support/kb.



Refer to the product manual for more detailed instructions. If you need further assistance, contact ZTEC Support by visiting www.ztecinstruments.com/support and opening a support ticket or by calling **1-866-ZTEC-NOW**.